



ONLY AVAILABLE FROM TECHCITYGAMING.COM

## **DRAGONFIRE USER GUIDE**

WHEN YOU FIRST TURN ON YOUR CONTROLLER  
DRAGONFIRE WILL BE SWITCHED OFF AND YOUR  
CONTROLLER WILL OPERATE AS NORMAL.

### **TO TURN ON DRAGONFIRE**

TO TURN ON DRAGON FIRE TAP THE  
SYNC/TACTILE BUTTON.



SHOWN AS IN THIS USER GUIDE  
THE PLAYER 4 LED WILL LIGHT UP  
DRAGONFIRE IS NOW ACTIVE.

### **MODES**

DRAGONFIRE COMES WITH UPTO **50** MODES  
THE FIRST 10 ARE PRE-PROGRAMMED FOR EASY USE.

- 1.FEATURE MODE\*(NO RAPIDFIRE)**
- 2.COD5/BLACK-OPS 1**
- 3.COD BLACK-OPS 2**
- 4. COD MW3**
- 5.SLOW SPEED PATCH BUSTER**
- 6.HALO 4**
- 7.MW3 INSANE MODE**
- 8.HIGH SPEED PATCH BUSTER**
- 9.GTA SERIES**
- 10.GOW SERIES**

**\*FEATURE MODE HAS NO RAPIDFIRE FOR USE WITH  
POWER-UPS FOR AUTOMATIC WEAPONS**



**ADVANCED MODES**

**THE OTHER 40 MODES ARE AS FOLLOWS**  
**AND ARE INDICATED BY THE NUMBER OF FLASHES**  
**ON PLAYER 4 LED**

**11.11sps**

**12.12sps**

**13.13sps**

**14.14sps**

**15.15sps**

**16.16sps**

**17.17sps**

**18.18sps**

**19.19sps**

**20.20sps**

**21.21sps**

**ETC**

**ETC**

**ETC**

**44.44sps**

**45.45sps**

**46.50sps**

**47.75sps**

**48.100sps**

**49.150sps**

**50.200sps**



# **POWER-UPS**

**DRAGONFIRE COMES FULLY EQUIPED WITH A RANGE OF  
POWER-UPS THAT CAN BE ACTIVATED BY THE TOUCH OF  
A BUTTON AND INCLUDE**

**DROPSHOT  
JUMPSHOT  
AKIMBO  
AKIMBO MIMIC  
AUTO ADS**

**DROPSHOT WITH**



**CANCELATION**

**JUMPPSHOT WITH**



**CANCELATION**

**GIVING YOU MORE CHOICE AND FASTER SPEEDS  
THAN ANY OTHER KIT ON THE MARKET  
ALL AT THE TOUCH OF A BUTTON!!!!**



**HOW TO USE DRAGONFIRE  
50 MODE KIT**

**TO TURN ON DRAGONFIRE**  **(SYNC OR TACTILE)**

**TO MOVE UP MODES** 

**TO MOVE DOWN MODES**  **+**   
**(NOT AVAILABLE WITH STEALTH INSTALL)**

**TO QUICK OFF DRAGONFIRE** 

**TO RETURN FROM QUICK OFF**   
**(RESUMES IN CURRENT MODE WITH POWER-UPS)**

**TO ACTIVATE/DEACTIVATE JUMPSHOT**  **THEN** 

**TO ACTIVATE/DEACTIVATE DROPSHOT**  **THEN** 

**TO ACTIVATE AKIMBO/DUAL**  **THEN** 

**DROPSHOT WITH**  **CANCELATION**  **THEN** 

**JUMPSHOTWITH**  **CANCELATION**  **THEN** 

**DETAILS**



**MOST POWER UPS CAN BE USED IN ANY MODE WITH  
RAPID FIRE OR SELECT FEATURE MODE(MODE 1)  
TO USE POWER-UPS WITH NO RAPID FIRE FOR WHEN YOU  
USE AUTOMATIC WEAPONS.**

**DE-ACTIVATING POWER-UPS IS DONE IN THE SAME WAY  
AS ACTIVATING THEM.**

**AFTER THE FIRST 10 PRESET SET MODES THE ADVANCE  
MODES START AT 11sps AND INCREASE IN SPEED THE  
HIGHER THE MODE YOU SELECT.**

**TO INCREASE SPEED IN ADVANCED MODES SIMPLY**



**THE TACTILE OR SYNC BUTTON**

**TO DECREASE SPEED IN ADVANCED MODES**



**THEN**



**SYNC OR TACTILE BUTTON**

**(NOT AVAILABLE IN STEALTH INSTALL)**

**WHEN THE LAST SPEED/MODE IS REACHED**



**AGAIN WILL TURN OFF DRAGONFIRE  
AND ALL POWER-UPS WILL BE DISABLED**